IAC Ch 90, p.1

**875—90.8(89)** Certificate. A certificate to operate shall not be issued until the boiler or pressure vessel is in compliance with the applicable rules and all fees have been paid. The current certificate to operate or a copy of the current certificate to operate shall be conspicuously posted in the room where the object is installed.